

ORDER OF INSTALLATION AND CONNECTION OF PARTS

(see Installation Instructions for details)

Installation methods:

SPC Panels: Flat Installation (adhesive)

Wood Slats Ash: Finishing nails through face on the frame of furring boards (included). Nails: #16, 2-2.5" long.

